

Advanced Magnetic Tape Technology for Linear Tape Systems


Barium ferrite technology beyond the limitation of metal particulate media

Osamu Shimizu, Takeshi Harasawa and Hitoshi Noguchi
FUJIFILM Corporation

Contents


1. Trends of Capacity per Cartridge.
2. Capacity increase in Metal Particulate (MP) media.
3. Barium ferrite (BF) technology in comparison with MP media.
4. Summary.

Capacity Trends




Enterprise roadmap source: http://www.oracle.co.jp/events/jpm120809/materials/20120809-10_StorageSumit_A-2.pdf
LTO roadmap source: <http://www.lto.org/technology/index.html>

Capacity Trends



Enterprise roadmap source: http://www.oracle.co.jp/events/jpm120809/materials/20120809-10_StorageSumit_A-2.pdf
LTO roadmap source: <http://www.lto.org/technology/index.html>


Capacity Trends



Enterprise roadmap source: http://www.oracle.co.jp/events/jpm120809/materials/20120809-10_StorageSumit_A-2.pdf
LTO roadmap source: <http://www.lto.org/technology/index.html>

Contents

1. Capacity Trends.
2. Capacity increase in Metal Particulate (MP) media.
3. Barium ferrite (BF) technology in comparison with MP media.
4. Summary.



- Thinner magnetic layer makes signal resolution higher, resulting to the achievement of higher linear density.

Capacity increase in MP media

ATOMM Technology

Thickness (t) 110nm
Deviation (δ) 25nm
 δ/t 23%




Magnetic layer

Under layer

50nm

NANOCUBIC Technology

Thickness (t) 60nm
Deviation (δ) 6nm
 δ/t 10%




Magnetic layer

Under layer

- Thickness variation of magnetic layer is negligibly small by NANO-coating technology.


Smoother surface profile




- Smoother surface reduce the spacing between head and media, resulting the significant increase of the signal output at higher linear density region.

Capacity increase in MP media

ATOMM Technology (LTO-1)
Ra:5.2nm




NANOCUBIC Technology (LTO-5)
Ra:2.6nm




- Creates very smooth tapes by NANO-dispersion technology,

Capacity increase in MP media




- Thinner tape makes longer tape windable in a same size of cartridge.



- Smaller magnetic particles are essential to a higher recording density .

Capacity increase in MP media



- Increasing the magnetic coersivity while reducing the particle size down to 3,000 (nm³).

Microscopic Comparison of Metal Magnetic Particles

ATOMM technology

NANOCUBIC Technology





- Creates new high coersivity metal particles that is just 35nm in size and 2850 nm³ in volume by Nano-particle technology


Contents

1. Capacity Trends.
2. Capacity increase in Metal Particulate (MP) media.
3. Barium ferrite (BF) technology in comparison with MP media.
4. Summary.

BF technology


	MP	BF
Particle Shape	 <p>Acicular</p>	 <p>Hexagonal platelet shaped</p>
Origin of magnetic energy	Shape anisotropy	Magneto-crystalline anisotropy
Material	FeCo alloy	$\text{BaO}(\text{Fe}_2\text{O}_3)_6$ Oxide
Passivation layer	Required	Not Required

- The magnetic property of barium-ferrite particle is NOT affected from its shape.
 - The barium-ferrite particle does NOT need the passivation layer because it is oxide from the beginning.
- ➔ The size of barium ferrite particle can be reduced with maintaining high coercivity.



- Reducing the particle size less than 3,000 (nm³) declined the magnetic coercivity, which is very important to keep the information, resulting the saturation of capacity increase with metal particles

BF technology




- Coercivity of barium ferrite particles is independent of their size. Smaller particles can be utilized for higher capacity.

TEM image of fine Barium-ferrite particles


Latest MP

Volume: 2850 nm³
coercivity: 2380 [Oe]




BF


Volume: 1600 nm³
coercivity: 2400 [Oe]



- Even the volume of barium ferrite shown above is 45 % smaller than the latest MP, their coercivity can be maintained.







- Barium ferrite media are stable enough even in the very hot and humid conditions.



- Barium ferrite media are stable enough even in the corrosive atmosphere (Battelle Class II, 14 days).


BF technology

	Initial	After exposure
BF		
MP		


- Barium ferrite media are stable enough even in the corrosive atmosphere (Battelle Class II, 14 days).

SEM Image of tape surface

Latest MP tape





BF Tape





- Barium ferrite particles are well isolated and packed in the high density.

Particle Orientation



MP tape



BF tape (product tape)



BF tape (newly developed tape)




- Barium ferrite particles can be oriented perpendicularly while MP are oriented longitudinally.

BF technology


Surface Design Concept

Low friction with narrow spacing

Conventional “Wavy” surface






Newly developed “Asperous” surface






- Asperous surface can reduce the friction without increasing the spacing.

BF technology





Optical
interferometry
roughness
meter



AFM




- The surface profile of latest MP and BF product are similar but that of newly developed BF is not “Wavy” but “Asperous”.



AITiC: Mixture of Al_2O_3 and TiC, Substrate Material of Magnetic Heads
Running speed: 14mm/sec


- The friction of BF product is lower than MP even though surface profile of them are similar. In addition, The friction of newly developed BF is lowest

BF technology




Enterprise roadmap source: http://www.oracle.co.jp/events/jpm120809/materials/20120809-10_StorageSumit_A-2.pdf
LTO roadmap source: <http://www.lto.org/technology/index.html>

BF technology




Enterprise roadmap source: http://www.oracle.co.jp/events/jpm120809/materials/20120809-10_StorageSumit_A-2.pdf
LTO roadmap source: <http://www.lto.org/technology/index.html>

BF technology



Enterprise roadmap source: http://www.oracle.co.jp/events/jpm120809/materials/20120809-10_StorageSumit_A-2.pdf
LTO roadmap source: <http://www.lto.org/technology/index.html>

BF technology



Enterprise roadmap source: http://www.oracle.co.jp/events/jpm120809/materials/20120809-10_StorageSumit_A-2.pdf
LTO roadmap source: <http://www.lto.org/technology/index.html>

Summary

- The Capacity of magnetic tape cartridge has been increased by reducing
 - Particle volume,
 - Magnetic layer thickness,
 - Surface roughness, and
 - Total tape thickness.
- Increasing cartridge capacity using MP with keeping long term stability becomes difficult because MP no longer can reduce their size without reducing coercivity.
- BF particles are very promising magnetic particles and more than 100 TB per cartridge will be realized using BF in several years.

80th
Anniversary

FUJIFILM
Value from Innovation